

2013+ Ford Interceptor Sedan Monitor Installation

Remove (2) 8mm Bolts that hold the plastic dash tray.



Remove tray and create a hole for wire pass through.

- Make sure to run cables through dash before completing the remaining steps.
- Remaining pictures are taken without cable connected for your reference.



Align adapter plate to existing holes



Secure adapter plate with existing 8mm bolts.



Align the monitor mount and secure with the (4) 7/16th locking nut provided.



Use four (4) provided 10-32 x 3/8" Phillips pan head screws to secure the monitor mount to the back of the EDGE monitor.



Completed monitor install, make sure the monitor can rotate left & right.



Monitor Folded

