

Body*V*ision XV



Quick Reference Card



Mobile-Vision, Inc.

Ready...Set...Record

Configure Your BodyVISION

To configure your new BodyVISION, read the "Getting Started" section in the *BodyVISION XV User's Guide*:

<http://s6.parature.com/FileManagement/Download/0be11479e6ad46bbb5e3213bc110b625>

Attach the BodyVISION



To attach a BodyVISION XV to your belt or clothing, first determine which type of clip will work best for you: *belt* clip (pictured) or *alligator* clip. Next, examine the clip on the back of the unit to make sure it's facing in the direction you want: *left*, *right*, or *down*. For example, if you plan to clip the unit to the pocket of your shirt, you would position the clip in the *down* position.

If you are clipping your BodyVISION to a magnetic mount, review the Magnetic Mount Instructions:

<http://s6.parature.com/FileManagement/Download/de74a9346e104d17ba455510325175d2>

Start/Stop a Recording

To initiate a recording, slide the record switch to the ON position, which is to the *left* if you are wearing the device or to the *right* if you are facing the device. As long as the video is in progress, the Status LED will flash red (if mute is *off*) or yellow/red (if mute is *on*) once every 5 seconds.

To start a recording, slide this switch to the *left* if you are wearing the device or to the *right* if you are facing the device



To *stop* a recording, move the record switch to the *right* if you are wearing the device or to the *left* if you are facing the device.

Turn Audio Mute On/Off

To mute a recording, press and hold the *Mute* button for two seconds. As long as the mute feature is in effect, the Status LED will flash yellow either every five seconds (for video recordings) or every two seconds (for VLP2 audio recordings).



To mute a recording, press this button for 2 seconds

Capture a Snapshot/Insert a Trace Point

1. If you've already programmed your BodyVISION to capture snapshot still images and/or insert Trace Point placemarkers, skip to step 5. Otherwise proceed to the next step.
2. Login to your video management software (i.e., DEP, DEA Precinct, DEV, DEF, or Basic Viewer HD).
3. Open the BodyVISION record.
4. Select **Snapshot**, **Tracepoint**, or **Both** from the *Snapshot/Tracepoint* drop-down list.
5. Press the *Snapshot/Tracepoint* button on the top of the unit while a recording is in progress.



To capture a snapshot image and/or insert a Trace Point, press this button

Check Recording Time Left

To determine how much record time you have left on your BodyVISION, make sure the unit is in *idle* mode (i.e., not recording), then press and release the *Stealth/Record Time* button. An LED light will display for five seconds.

- > 5 hours left
- > = 1.5 hours and < = 5 hours left
- < 1.5 hours left

To check your remaining record time, press and release this button



Color of Status LED tells you how much record time you have left

Turn 'Stealth' Mode On/Off

In Stealth mode, the vibrations, LED lights, and audio beeps are disabled, allowing you to record discreetly in covert situations.

To turn Stealth mode *on*, press and hold the *Stealth/Record Time* button for three seconds while recording or in *idle* mode. To turn Stealth mode *off*, repeat the procedure.

To turn Stealth mode on/off, press this button for 3 seconds



For More Information...

Watch the BodyVISION XV training video:

<http://s6.parature.com/FileManagement/Download/3ad39d59f5294416a427aa9887aae266>



Mobile-Vision, Inc.