

At the beginning of each shift/day, please check the following to ensure they are working properly.

-	_	_	_	
r				١.
				L
L				L
L				
-	-	-	-	

Turn the vehicle on > 360 HD system turns on

1) Check Cameras



Verify that the Default Live View (360° + Left Cam) displays after startup.



Use the Driver/View (green) button to cycle through all 6 views on the monitor:

```
Top + Left \bigcap Top + Front \bigcap
                           Top View
```

Top + Right \bigcap Top + Back \bigcap 4 Cam Split

2) Check Signals



Activate left turn signal > Monitor displays the left camera view.



Activate right turn signal > Monitor displays the right camera view

Place the vehicle in reverse > Monitor displays rear camera view with back-up lines.

Check Events*

- Press the Event/Panic (red) button > Verify that "Event Recorded" appears on on the monitor.
 - * You might not want to press this button every time you start up the vehicle, as it would result in multiple "panic" events being recorded.

4) Check Outriggers*

- Press the Outrigger/Overlay (black) button > Verify that red bars appear on the 360° image
 - * If your vehicle has outriggers but you do not see overlays, contact your administrator.

Customer Support

- Phone: 1.844.899.7366
- Support Hours: Monday Friday: 7:00am 7:00pm EST